CyberLock®

Event	Green LED	Red LED	Notes
Access Granted	Steady on	Off	LED remains on for duration of solenoid hold time or until key is removed from lock.
Access Denied (expired or out of schedule)	Off	Long flash once per second	–
Key Expired	On for 1 second	3 flashes	Occurs after Access Denied pattern, if "flash after expiration" is set. Pattern repeats until key is updated or battery is drained.
Access Denied (no permissions OR wrong access codes)	Off	Rapid flash	–
Battery OK	1 flash every 8 seconds	Off	–
Battery Low	Off	One flash every 8 seconds	Occurs until key is placed in charger or battery is drained.
Battery Charging	Off	Short flash once per second	Occurs while in charger or idle in USB station.
Battery Charged	Short flash once per second	Off	Occurs while in charger or idle in USB station.
Battery Dead	Off	Off	–
Communications	Irregular flashing	Irregular flashing	–
CyberPoint Contact	Steady on	Rapid flash	–
Download Lock	Steady on with slight flicker	Steady on with slight flicker	–
Resetting a Lock (as a subsystem reset key)	Steady on	3 flashes	–
Delay Instruction Received from Lock–Key in Lock	Steady on	3 flashes	–
Delay Time Has Been Served–Key Out of Lock	On for 1 second	3 flashes	Pattern continues for 3 to 5 minutes.
Key Left in Lock	Rapid flash	1 flash after each minute	–
Multi-Key Access	Steady on	3 flashes for each key after the first	–
Key Disabled	On for 1 second	3 flashes	Pattern repeats until key is updated or battery is drained.